


Wellis®



EN

Edge 120 bath screen
INSTRUCTION MANUAL

DE

Edge 120 Badschirm
BEDIENUNGSANLEITUNG

FR



Edge 120 ÉCRAN DE BAIGNOIRE
MODE D'EMPLOI


HU


Edge 120 kádparaván
HASZNÁLATI UTASÍTÁS

WC00329

EDGE 120













①		AL052	X 1
②		A	X 1
③		ST4X30	X 5
④		JT005-01	X 1
⑤		B	X 1
⑥		PL062	X 1
⑦		HD031	X 1
⑧		PL066	X 1
⑨		PL041	X 3
⑩		PL063	X 2
⑪		ST4X8	X 2
⑫		ST4X30	X 1
⑬		HD034	X 1
⑭		M5x5	X 2
⑮		JT015	X 2
⑯		PL065	X 1





1








2










3








4



5



6



Wellis®

CE